

Disabling Daytime Running Lights

<http://forums.tdiclub.com/showthread.php?t=78046>

Author: Rammstein@TDIClub


5/14/04

You just got your Euroswitch and want the DRL's off when your switch is at the "all off" position?

Or maybe you want an all off position on your regular switch?

Easy.

First locate the DRL relay:



A more distant picture:



As you see the relay is besides the N75 on the firewall, behind the coolant reservoir.

Just press the metal clips and pull on the bottom piece to get it out.

It can be real tough if the relay has never been touched.

Try twisting it until you get it out.

As you see, I've kinda put it back in, but not fully.